



| Product | Description | Pkg | Each |
|--|---|-----|------|
| GENERAL TOOLS AND HOSE ADAPTERS | | | |
| 48036 | Utility Pump 36" Long | 1 | |
| I-PUMP | Sprinkler Hand Pump (pictured above) | 1 | |
| 630-QC | Hose Adapter for 1" Golf Sprinkler Bodies | 1 | |
| 363-4102 | & O-Ring for 1" Body | 1 | |
| 670-QC | Hose adapter for 1.5" golf bodies | 1 | |
| 363-4103 | & O-Ring for 1.5" Body | 1 | |
| 075-MHS | 1" NPT x 3/4" Hose Swivel | 1 | |
| 100-MHS | 1" NPT x 1" Hose Swivel | 1 | |

| Product | Description | Pkg | Each |
|--|---|-----|------|
| 1" GOLF BODY - TOOLS AND ACCESSORIES | | | |
| (All Models: 630, 660, 720, 730, 760, 830S and 860S Series) | | | |
| 995-100 | Valve Snap Ring Pliers with Screen Remover | 1 | |
| 995-08 | Valve Removal Tool | 1 | |
| 995-15 | Selector Tool (Flag Key) | 1 | |
| 995-49 | Pressure Gauge | 1 | |
| 995-50 | Pitot Tube | 1 | |
| 995-51 | Pressure Gauge Kit (Includes 995-49 & 995-50) | 1 | |
| 995-76 | Valve Insertion Tool | 1 | |
| 995-83 | Multi-purpose Tool | 1 | |
| 630 SERIES | | | |
| 995-06 | Drive Assembly Extraction Tool | 1 | |
| 995-16 | Riser Pliers | 1 | |
| 995-31 | Hose Adapter | 1 | |
| 660 SERIES | | | |
| 995-52 | Nut Driver, 1/4" | 1 | |
| 995-53 | Nut Driver, 3/8" | 1 | |
| 995-55 | Riser Hold-up Tool | 1 | |
| 730 SERIES | | | |
| 995-55 | Riser Hold-up Tool | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 760 SERIES | | | |
| 995-55 | Riser Hold-up Tool | 1 | |
| 995-79 | Nut Driver, 7/16" (For Inner Nozzle) | 1 | |
| 995-80 | Nut Driver, 1/2" (For 363-3137 Jam Nut) | 1 | |
| 995-81 | Nut Driver, 9/16" (For Main Nozzle) | 1 | |
| 995-82 | Arc Adjustment Tool, 3/32" (T-handle Hex Wrench) | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 830S SERIES | | | |
| 995-102 | Riser Hold-up Tool, Universal | 1 | |
| 995-79 | Nut Driver, 7/16" (for Inner nozzle, pre-Aug=07) | 1 | |
| 995-105 | Nut Driver, 5/16" (for Inner nozzle, post-Aug 07) | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 835S and DT34/DT35 SERIES | | | |
| 995-102 | Riser Hold-up Tool, Universal | 1 | |
| 995-105 | Nut Driver, 5/16" | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 995-99 | Nut Driver, 5/8" (For Main Nozzle) | 1 | |
| 860 SERIES | | | |
| 995-102 | Riser Hold-up Tool, Universal | 1 | |
| 995-79 | Nut Driver, 7/16" (For Inner Nozzle) | 1 | |
| 995-80 | Nut Driver, 1/2" (For 363-3137 Jam Nut) | 1 | |
| 995-82 | Arc Adjustment Tool, 3/32" (T-handle Hex Wrnch) | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 995-99 | Nut Driver, 5/8" (For Main Nozzle) | 1 | |



| Product | Description | Pkg | Each |
|--|---|-----|------|
| 1-1/2" GOLF BODY - TOOLS AND ACCESSORIES | | | |
| (all models: 650, 670, 680, 750, 780, 850S and 880S Series) | | | |
| 995-09 | Valve Removal Tool | 1 | |
| 995-101 | Valve Insertion Tool | 1 | |
| 995-15 | Selector Tool (Flag Key) | 1 | |
| 995-49 | Pressure Gauge | 1 | |
| 995-50 | Pitot Tube | 1 | |
| 995-51 | Pressure Gauge Kit (Includes 995-49 & 995-50) | 1 | |
| 995-83 | Multi-purpose Tool | 1 | |
| 650 SERIES | | | |
| 995-06 | Drive Assembly Extraction Tool | 1 | |
| 995-100 | Valve Snap Ring Pliers with Screen Remover | 1 | |
| 995-16 | Riser Pliers | 1 | |
| 995-18 | Spring Collar Installation Tool | 1 | |
| 995-31 | Hose Adapter | 1 | |
| 995-79 | Nut Driver, 7/16" (For Inner Nozzle) | 1 | |
| 670 SERIES | | | |
| 995-100 | Valve Snap Ring Pliers with Screen Remover | 1 | |
| 680 SERIES | | | |
| 995-52 | Nut Driver, 1/4" | 1 | |
| 995-53 | Nut Driver, 3/8" | 1 | |
| 995-55 | Riser Hold Up Tool | 1 | |
| 750 SERIES | | | |
| 995-55 | Riser Hold-up Tool | 1 | |
| 995-83 | Multi-purpose Tool | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 780 SERIES | | | |
| 995-55 | Riser Hold-up Tool | 1 | |
| 995-79 | Nut Driver, 7/16" (For Inner Nozzle) | 1 | |
| 995-80 | Nut Driver, 1/2" (For 363-3137 Jam Nut) | 1 | |
| 995-81 | Nut Driver, 9/16" (For Main Nozzle) | 1 | |
| 995-82 | Arc Adjustment Tool, 3/32" (T-handle Hex Wrnch) | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 850S SERIES | | | |
| 995-102 | Riser Hold-up Tool, Universal | 1 | |
| 995-79 | Nut Driver, 7/16" (For Inner Nozzle) | 1 | |
| 995-105 | Nut Driver, 5/16" (For Inner Nozl, Post-Aug 2007) | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 995-99 | Nut Driver, 5/8" (For Main Nozzle) | 1 | |
| 855S and DT54/DT55 SERIES | | | |
| 995-102 | Riser Hold-up Tool, Universal | 1 | |
| 995-105 | Nut Driver, 5/16" | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 995-99 | Nut Driver, 5/8" (For Main Nozzle) | 1 | |
| 880S SERIES | | | |
| 995-102 | Riser Hold-up Tool, Universal | 1 | |
| 995-79 | Nut Driver, 7/16" (For Inner Nozzle) | 1 | |
| 995-80 | Nut Driver, 1/2" (For 363-3137 Jam Nut) | 1 | |
| 995-82 | Arc Adjustment Tool, 3/32" (T-handle Hex Wrenc) | 1 | |
| 995-85 | Riser Removal Tool | 1 | |
| 995-99 | Nut Driver, 5/8" (For Main Nozzle) | 1 | |
| 690 SERIES BODY - TOOLS AND ACCESSORIES | | | |
| 995-06 | Drive Assembly Extraction Tool | 1 | |
| 995-100 | Valve Snap Ring Pliers with Screen Remover | 1 | |
| 995-09 | Valve Removal Tool | 1 | |
| 995-12 | Valve Insertion Tool | 1 | |
| 995-15 | Selector Tool (Flag Key) | 1 | |
| 995-17 | Riser Pliers | 1 | |
| 995-20 | Valve Insertion Tool, Rubber Cover | 1 | |
| 995-22 | Hose Adapter | 1 | |
| 995-83 | Multi-purpose Tool | 1 | |
| 102-5011 | 690 Conversion Kit | 1 | |